

LEGENDS FLASHBACK

Instruction Manual

MODEL NO.: FB8660

Legends Flashback Game Console Appearance and Key List

The image below shows the location of the connectors and buttons. Each function is outlined below the image.

1 Power ON/OFF

2 MENU

3 First Player Game Controller Jack

4 Second Player Game Controller Jack


5 SD Card Slot

6 HDMI Output

7 Micro-USB Adaptor Jack

NOTE

- Must use the Micro-USB adaptor included as the power supply to the console.
- Do not connect the Micro-USB adaptor to a power input other than the below specifications.
- Micro-USB adaptor is not a toy.
- The socket-outlet should be installed near the equipment and should be easily accessible.



What do I do when the power supply is not working?

You might be using the wrong Micro-USB adaptor. Please use the one included in the package, which is rated for 5V/1A.

Micro-USB Adaptor Specification

INPUT:
100V-240V AC/50HZ-60HZ
OUTPUT: 5V/1A

How to connect the console to a HD TV?

Connect the game console to TV using an HDMI cable.

NOTE: HDMI cable is not included.

POWER

Press the power button on the game console after configuring the TV input to the selected HDMI source.

NOTE

Display results will vary by TV. Consult your TV's manual to adjust Brightness, Sharpness, Contrast, Aspect Ratio, and other features for best display results.

Wired Game Controller

Appearance and Key List

The image below shows the location of the connectors and buttons. Each function is outlined below the image.

1 START

Press the button to start the game and press it again to pause in some of the games.

2 Directional Pad (D-Pad)

3 A Key

4 X Key

4 B Key

7 Y Key

5 C Key

8 Z Key



How Do I Use Wired Controllers?

What are the two controller ports on the console for?

These ports are for the wired controllers.

These ports are also compatible with original Sega Genesis wired controllers.

How do I connect wired controllers?

For 1 player games:

Connect a wired controller to the left controller port.

For 2 player games:

Connect a second wired controller to the right controller port for player two.

NOTE: Some two player games alternate use of the player one controller.


What do I do when the controller is not working?

1. If you only have a controller plugged into the P2 socket, turn off your console and connect the controller to the P1 (left) controller port. Then, turn on the console and try again.

2. If you have a controller plugged into the P1 socket, please turn the console off and restart.

(Purchase additional accessories at www.atgames.us)

How do I start playing?



How do I play two-player games?

1. Follow the steps in section "How do I start playing".
2. Press **↑** or **↓** on **+** to select a two player game.
3. **START** Press START on the P1 controller to start playing the game.

How do I go back to game menu while playing the game?

Press the button to display in-game menu, select QUIT GAME to go back to the game menu page.

How do I rewind the game?

Press and hold the Left button on the D-Pad and press START with P1 controller.



Using SD Card

How to upgrade the console via SD card?

- 1 Insert SD card into your PC.
- 2 Download firmware from AtGames Flashback Zone.
- 3 Change the file name to arcade_update.img.
- 4 Place the file on the SD card.
- 5 Insert the SD card into your console, then turn the console on.
- 6 The request page will pop up once the console is turned on. Choose YES to start upgrading.
- 7 The console will automatically restart after the update is applied.

NOTE:

- 1.The request page will pop up again when the console restarts. Choose NO to return to the Main Menu.
- 2.While upgrading the firmware, please let the device remain on and SD card intact in the device to avoid system error.
- 3.This product is compatible with SD cards that are 16 GB (Gigabyte) or less.

Safety Notice

Do not submerge the game console in water or expose it to extreme heat or to strong magnetic fields. Doing so may cause permanent damage to your game player. Always use a dry towel to clean the game console and controllers. Transformers are suitable for indoor use only. Transformers and power supplies for toys are not intended to be used as toys, and the use of these products by children shall be under the full supervision of parents.

GAME LIST (100)

1942™	Gargoyles	Shoot Out
Act-Fancer Cybernetick Hyper Weapon	Ghouls 'n Ghosts™	Side Pocket
Aladdin	Heavy Barrel	Sky Fox
Artillery Duel™	Hoops	SKY KID™
Astro Fantasia	HyperDyne Side Arms™	Space Fury™
Bad Dudes vs. Dragon-ninja	Joe & Mac Returns	Space Panic™
Brave Battle Sage: Legend of the Magic Warrior	Joe & Mac : Caveman Ninja	Strider™
Break Thru	Judge Dredd® 95	Super BurgerTime
BurgerTime	Jumpman Junior™	Super Doubles Tennis
Burnin' Rubber(arcade)	Jungle Hunt	Super Pool III
Burnin' Rubber (ColecoVision)	Lock 'n' Chase	Super Real Darwin
Champions World Class Soccer	MAPPY™	Super Star Wars
Choplifter!™	Mega Man™	Super Star Wars: Return of the Jedi
City Connection	Mega Man 2™	Super Star Wars: The Empire Strikes Back
Cluster Buster	Meikyu Hunter G	Super Street Fighter II: The New Challengers™
Commando™	Miner 2049er™	Sword of Sodor
Cosmic Avenger™	Montezuma's Revenge™	Terranean
Crude Buster	Moonsweeper™	Tetris®
Darwin 4078	Nova Blast™	Tetris® Plus 2
DIG DUG™	Oil's Well™	The Ashtanax
Disco No.1	Omega Race™	The Gadget Twins
Donald in Maui Mallard	R-47: The Freedom Fighter	The Jungle Book
Dragonfire™ (ColecoVision)	Pepper II™	The Lion King
E.D.F. Earth Defense Force	PHELIOS™	Thunderbolt II
Edward Randy, The Cliffhanger	Pinball Quest	Tinhead
Exerion	Pirate Ship Higemaru™	Top Gear 2
Express Raider	Pro Bowling	Totally Rad
Fighting Ice Hockey	Pro Tennis	Tournament Pro Golf
Fix-It Felix, Jr.	RALLY-X™	Venture™
Forgotten Worlds™	Rod-Land	Victory
Formation Z	Rootin' Tootin'	Water Margin - The Tale of Clouds and Wind
Frenzy™	Saint Dragon	Zaxxon™
GALAGA™	Scrum Try	Zombies Ate My Neighbors
	Secret Agent / Sly Spy	



SCAN
AND FIND OUT MORE
ABOUT THIS PRODUCT!
More Classics at www.atgames.us

AtGames

© 2019 AtGames Interactive
www.atgames.net

PO Box 1691, El Segundo, CA 90245
All rights reserved.

DATA EAST and DATA EAST logo(s) are trademarks in United States and other countries or registered trademarks in European Union and Japan of G-MODE Corporation.

Copyright © 1993-2019 Throwback Entertainment Inc. All Rights Reserved.

JUDGE DREDD IS A REGISTERED TRADE MARK® and ©REBELLION A/S ALL RIGHTS RESERVED. USED UNDER LICENCE.

Acclaim™ is a trademark of CollectorVision Games Inc. and is used under license to AtGames © 2019 CollectorVision Games Inc. ALL RIGHTS RESERVED

© Capcom LICENSED FOR USE BY ATGAMES.

1942 ©CAPCOM CO., LTD. 1984, 2019 ALL RIGHTS RESERVED.
Commando ©CAPCOM CO., LTD. 1985, 2019 ALL RIGHTS RESERVED.

Forgotten Worlds ©CAPCOM CO., LTD. 1988, 2019 ©CAPCOM U.S.A., INC. 1988, 2019 ALL RIGHTS RESERVED.

Ghouls 'n Ghosts ©CAPCOM CO., LTD. 1988, 2019 ALL RIGHTS RESERVED.

HyperDyne Side Arms ©CAPCOM CO., LTD. 1986, 2019 ALL RIGHTS RESERVED.

Mega Man ©CAPCOM CO., LTD. 1987, 2019 ALL RIGHTS RESERVED.
Mega Man 2 ©CAPCOM CO., LTD. 1988, 2019 ©CAPCOM U.S.A., INC. 1988, 2019 ALL RIGHTS RESERVED.

Pirate Ship Higemaru ©CAPCOM CO., LTD. 1984, 2019 ALL RIGHTS RESERVED.
Strider ©CAPCOM CO., LTD. 1989, 2019 ©CAPCOM U.S.A., INC. 1989, 2019 ©MOTO KIKAKU ALL RIGHTS RESERVED.

Super Street Fighter 2 ©CAPCOM CO., LTD. 1991, 1993, 2019 ©CAPCOM U.S.A., INC. 1991, 1993, 2019 ALL RIGHTS RESERVED.



DIG DUG™&©2019 BANDAI NAMCO Entertainment Inc.
MAPPY™&©2019 BANDAI NAMCO Entertainment Inc.
GALAGA™&©2019 BANDAI NAMCO Entertainment Inc.
RALLY-X™&©2019 BANDAI NAMCO Entertainment Inc.
SKY KID™&©2019 BANDAI NAMCO Entertainment Inc.
THE LION KING™&©2019 BANDAI NAMCO Entertainment Inc.
Licensed by BANDAI NAMCO Entertainment America Inc.

HDMI

The Adopted Trademarks HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

With certain TV models(Samsung PN42C450; SONY KDL-32EX500; Samsung LN32B640R3F), sounds outputs may abnormally while playing the certain games. If this happens, try the console on a different display or return the console to the point of purchase.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.